
PRE-DELIVERY INSPECTION

id000000801100

Pre-Delivery Inspection Table

Exterior

INSPECT and **ADJUST**, if necessary, the following items to specification:

- ☐ Glass, exterior bright metal and paint for damage
- ☐ Wheel lug nuts
- ☐ All weatherstrips for damage or detachment
- ☐ Tire pressures
- ☐ Headlight cleaner and fluid level (if equipped)
- ☐ Operation of bonnet release and lock
- ☐ Operation of trunk lid and fuel-filler lid opener
- ☐ Door operation and alignment including side door and back door
- ☐ Headlight aiming

INSTALL the following parts:

- ☐ Flap (front)
- ☐ Wheel caps or rings (if equipped)

Under bonnet—engine off

INSPECT and **ADJUST**, if necessary, the following items to specification:

- ☐ Fuel, engine coolant, and hydraulic lines, fittings, connections, and components for leaks
- ☐ Engine oil level
- ☐ Brake and clutch fluid level
- ☐ Windshield washer reservoir fluid level
- ☐ Radiator coolant level and specific gravity
- ☐ Tightness of water hose clamps
- ☐ Tightness of battery terminals, electrolyte level and specific gravity

Interior

INSTALL the following items:

- ☐ Fuse for accessories

INSPECT the operations of the following items:

- ☐ Seat controls (slide and recline) and headrests
 - ☐ Folding rear seat
 - ☐ Door locks, including childproof door locks
 - ☐ Seat belts and warning system
 - ☐ Ignition switch and steering lock
 - ☐ Transmission/Transaxle range switch
 - ☐ Warning buzzers
 - ☐ Ignition key reminder alarm
 - ☐ Air bag system using warning light
 - ☐ Cruise control system (if equipped)
 - ☐ Power door lock
 - ☐ Shift-lock system (if equipped)
 - ☐ Starter interlock
 - ☐ All lights including warning, and indicator lights
 - ☐ Horn, wipers, and washers
 - ☐ Wiper blades performance
- Clean wiper blades and windshield, if necessary
- ☐ Antenna
 - ☐ Audio system
 - ☐ Cigarette lighter and clock
 - ☐ Power windows (if equipped)
 - ☐ Heater, defroster, and air conditioner at various mode selections (if equipped)
- INSPECT** the following items:
- ☐ Presence of spare fuse
 - ☐ Upholstery and interior finish
- INSPECT** and **ADJUST**, if necessary, the following items:
- ☐ Operation and fit of windows
 - ☐ Pedal height and free play of clutch pedal
 - ☐ Parking brake

Under bonnet—engine running at operating temperature

INSPECT the following items:

- ☐ Automatic transmission/Transaxle fluid level

-
- ☐ Operation of idle-up system for electrical load, air conditioner or power steering (if equipped)
 - ☐ Ignition timing
 - ☐ Idle speed
 - ☐ Operation of throttle position sensor

On hoist

INSPECT the following items:

- ☐ Manual transmission/Transaxle oil level
- ☐ Underside fuel, coolant and hydraulic lines, fittings, connections, and components for leaks
- ☐ Tires for cuts or bruises
- ☐ Steering linkage, suspension, exhaust system, and all underside hardware for looseness or damage

Road test

INSPECT the following items:

- ☐ Brake operation
- ☐ Clutch operation
- ☐ Steering control
- ☐ Operation of gauges
- ☐ Squeaks, rattles, and unusual noises
- ☐ Engine general performance
- ☐ Emergency locking retractors and automatic locking retractors
- ☐ Cruise control system (if equipped)
- ☐ Operation of meters and gauges, squeaks, rattles, and abnormal noises

After road test

INSPECT for necessary owner information materials, tools, and spare tire in vehicle

The following items must be completed just before delivery to your customer.

- ☐ Load test battery and charge if necessary (Load test result: Volts)
- ☐ Adjust tire pressure to specification (Specified tire pressure is indicated on the door label.)
- ☐ Clean outside of vehicle
- ☐ Install fuses for accessories
- ☐ Remove seat and cabin carpet protective covers
- ☐ Vacuum inside of vehicle