
ABBREVIATIONS

id000000801000

ABS	Antilock Brake System
ACC	Accessories
ALC	Auto Level Control
ALR	Automatic Locking Retractor
AMB	Ambient
APP	Accelerator Pedal Position
ATF	Automatic Transaxle Fluid
ATX	Automatic Transaxle
BDC	Bottom Dead Center
BTDC	Before Top Dead Center
CAN	Controller Area Network
CCM	Comprehensive Component Monitor
CM	Control Module
DC	Drive Cycle
DSC	Dynamic Stability Control
EBD	Electronic Brakeforce Distribution
EHPAS	Electro Hydraulic Power Assist Steering
ELR	Emergency Locking Retractor
EX	Exhaust
GPS	Global Positioning System
HDD	Hard Disc Drive
HI	High
HU	Hydraulic Unit
IDS	Integrated Diagnostic Software
IG	Ignition
IN	Intake
INT	Intermittent
IPC	Instrument Panel Cluster
KOEO	Key On Engine Off
KOER	Key On Engine Running
LCD	Liquid Crystal Display
LF	Left Front
LH	Left Hand
L.H.D.	Left Hand Drive
LO	Low
LR	Left Rear
M	Motor
MAX	Maximum
MIN	Minimum
MTX	Manual Transaxle
OCV	Oil Control Valve
PAD	Passenger Air Bag Deactivation
PDS	Portable Diagnostic Software
PID	Parameter Identification
PJB	Passenger Junction Box
PM	Particulate Matter
P/S	Power Steering
P/W	Power Window
REC	Recirculate
RF	Right Front
RH	Right Hand
R.H.D.	Right Hand Drive
RR	Right Rear
SAS	Sophisticated Air Bag Sensor
SAE	Society of Automotive Engineers
SST	Special Service Tool
SW	Switch
TAC	Throttle Adjust Screw
TCS	Traction Control System
TDC	Top Dead Center

TFT	Transaxle Fluid Temperature
TNS	Tail Number Side Lights
VBC	Variable Boost Control
W/M	Workshop Manual
1GR	First Gear
2GR	Second Gear
3GR	Third Gear
4GR	Fourth Gear
5GR	Fifth Gear
6GR	Sixth Gear